



7	2	Set screw
6	2	Clear tube washer
5	4	Clear flat washer
4	2	Square screw
3	2	Round nut
2	1	Towel bar
1	1	Hex Key
Item #	QTY	Description

1) Loosen the two set screws [7] on both ends of the towel bar, turning counterclockwise, 2 to 2 and a 1/2 turns to disassemble the internal assembly. Disassemble and separate the internal assembly, [3],[4],[5] and [6].

2) From the inside, insert the square screw [4] with a clear flat washer [5] on clear tube washer [6] through one hole of the glass door. From the outside, insert the clear flat washer [5] and affix the round nut [3] on the screw by hand. Repeat the step for the other hole.

3) Line up the towel bar [2] with both nuts on the outside. Check straightness of the towel bar. Remove the towel bar and adjust the screws if needed. Otherwise, tighten the nuts, ensuring the square head screw is in line with the towel bar and the edge of the door. Ensure not to over tighten the nuts.

4) Insert the towel bar onto the two nuts. Check alignment and tighten the set screws [7].

